OPERATION:

Grasp both switch handle and front knob handle firmly. Turn tool "ON" and use tool freely without forced effort or excessive pressure. In most cases, the weight of the tool will provide sufficient pressure.

Move the sander in any direction over the work area. (When sanding wood, it is **not** necessary to sand only with the grain). Sand only long enough to obtain a smooth surface—cutting action is rapid and too much material may be removed by prolonged sanding.

For best results in wood sanding, sand first with coarse paper, then with medium paper, and last with fine paper. To obtain an exceptionally smooth surface, wet the wood with a rag or sponge and let the wood dry. The grain of the wood will then raise slightly and the surface will feel rough. Resand with B&D 150 or 4/0 grit paper for extra smooth results.




Fig. 2

FACTORY SALES and SERVICE CENTERS

Area Code	Telephone No.	Area Code	Telephone No.
ALABAMA 35233, Birmingham, 1717 Third Ave., So205	324-6691	NEW YORK 14209, Buffalo, 881 W. Delavan Ave716	TT 4-6220
ARIZONA 85007, Phoenix, 537 E. McDowell Rd602	AL 8-1332	10462, New York, 1894 E. Tremont Ave. (Bronx)212	SY 2-2700
ARKANSAS 72201, Little Rock, 519 West Seventh St501	FR 2-3040	10014, New York, 227 Varick St. (Manhattan)212	WA 9-6450
CALIFORNIA 92802, Anaheim, 1235 S. Euclid Ave714	772-4050	11377, New York, 56-15 Queens Blvd. (Woodside)212	DE 5-1042
90007, Los Angeles, 2432 S. Broadway213	RI 9-0371	14620, Rochester, 476 Clinton Ave., S716	454-3814
94606, Oakland, 1107 E. 14th St415	TE 4-5944	13224, Syracuse, 2140 Erie Blvd., E315	446-3086
95814, Sacramento, 1915 Seventeenth St	444-3188	NORTH CAROLINA 28206, Charlotte, 1710 W. Graham St704	FR 5-3721
92105, San Diego, 3811 El Cajon Blvd714	AT 1-3331	28306, Fayetteville, P.O. Box 4305, Highway 301, S919	425-1181
95050, Santa Clara, 2291 The Alameda408	241-9162	27403, Greensboro, 1032 West Lee St919	275-4487
94080, South San Francisco, 1139 Airport Blvd415	871-7278	OHIO 45203, Cincinnati, 1225 Western Ave513	421-2275
COLORADO 80204, Denver, 675 Kalamath St303	222-0621	44113, Cleveland, 3901 Detroit Ave216	OL 1-4243
CONNECTICUT 06114, Hartford, 131 Meadow St203	249-6241	43202, Columbus, 3293 N. High St614	AM 8-5797
FLORIDA 32208, Jacksonville, 5224 Pearl Street904	836-8351	45420, Dayton, 617 Watervliet Ave513	252-1821
33147, Miami, 2075 N. W. 54th Street305	356-2951	44139, Solon, 6225 Cochran Rd216	CH 8-5330
32806, Orlando, 940 So. Orange Ave305	NE 3-9839	43606, Toledo, 2629 W. Central Ave419	475-6771
33609, Tampa, 3407 S. Dale Mabry Hwy813	241-4015	OKLAHOMA 73106, Oklahoma City, 1717 Linwood Blvd405	CE 2-7515
GEORGIA 30313, Atlanta, 316 Techwood Dr., N.W404	JA 4-0431	74114, Tulsa, 2602 So. Harvard St918	747-1558
HAWAII 96813, Honolulu, 675 Auahi St808	569-374	OREGON 97209, Portland, 1640 N.W. Johnson St503	CA 8-8631
ILLINOIS 60607, Chicago, 1100 W. Jackson Blvd312	TA 9-3500	PENNSYLVANIA 17112, Harrisburg,	
60646, Chi., Lincolnw'd, 6710 N. Crawford Ave312	OR 3-0923	6070 Allentown Rd717	KI 5-0651
60655, Chicago, 10708 S. Western Ave312	BE 3-6832	17604, Lancaster, 715 Fountain Ave717	EX 3-5831
INDIANA 47708, Evansville, 931 Bond St812	425-4269	19103, Philadelphia, 333 N. 20th St215	LO 4-5520
46207, Indianapolis, 1125 W. 16th St317	632-5569	15232, Pittsburgh, 5437 Baum Blvd412	362-2700
IOWA 50312, Des Moines, 2811 Ingersoll Ave515	CH 4-7257	RHODE ISLAND 02914, East Providence,	4044055
KANSAS 67214, Wichita, 203 No. Mathewson St316	FO 3-6571	2777 Pawtucket Ave401	434-1655
KENTUCKY 40221, Louisville, 4407 Park Blvd502	366-1495	SOUTH CAROLINA 29601, Greenville, 407 Pendleton St803	232-3038
LOUISIANA 70112, New Orleans, 2010 Poydras St504	522-2544	TENNESSEE 37917, Knoxville, 1123 N. Central St615	546-2481
MARYLAND 21211, Baltimore, 203 W. 28th St301	HO 7-7411	38106, Memphis, 921 South Third St901	WH 2-3244
21205, Baltimore, 4712 Erdman Ave301	485-5550	37210, Nashville, 533 Fourth Ave., South	254-0110 DR 3-1531
20710, Bladensburg, 4501 Baltimore Ave301	779-3808	TEXAS 79106, Amarillo, 3008 West 6th Ave806	RI 1-6401
21204, Towson, 701 E. Joppa Rd301	VA 3-4400	75207, Dallas, 1808 N. Industrial Blvd214	ED 6-0175
MASSACHUSETTS 02135, Boston,	OT 0 COC4	76103, Fort Worth, 1801 Bomar St	CA 8-7521
12 Market St. (Brighton)	ST 2-6264	77003, Houston, 105 Sampson St713 78210, San Antonio, 1314 S. St. Mary's St512	LE 4-4611
MICHIGAN 48219, Detroit, 18133, W. McNichols Rd313	534-8880	UTAH 84115, Salt Lake City, 1541 S. Second West801	HU 6-7056
48234, Detroit, 11360 East Seven Mile Rd313	527-5010 534-7708	VIRGINIA 22046, Falls Church, 129 Annandale Rd703	533-1147
49509, Grand Rapids, 1296 36th St., S.W	TA-3-5283	23517. Norfolk, 337 West 21st St703	625-6888
MINNESOTA 55408, Minn., 2815 Nicollet Ave	HA 1-1493	23222. Richmond, 1424 Chamberlayne Ave703	649-9245
MISSOURI 64108, Kansas City, 2705 McGee Tfcwy816	JE 3-2210	WASHINGTON 98109, Seattle, 434 Eighth Ave. N206	MA 3-6442
63110, St. Louis, 615 S. Vandeventer Ave314 NEBRASKA 68102, Omaha, 2218 Leavenworth St402	345-2330	99202. Spokane, 3025A E. Mission Ave	KE 4-7188
NEW JERSEY 07104, Newark, 868 Broadway201	HU 3-1076	WEST VIRGINIA 25301, Charleston,	, 100
NEW MEXICO 87110. Albuquerque,	119 9-10/0	116 Washington St., East304	343-0289
4700 Lomas Blvd., N.E	265-6401	WISCONSIN 53213, Milwaukee, 6301 Blue Mound Rd414	GR 6-7800
7/00 LUMBS DIVU., II.L	200 0401		

BLACK & DECKER SALES AND SERVICE CENTRES

DLACK & DECKER SALES AT	AD STUAICE CEIALIVES
HALIFAX, N.S.: 803 McLean Street QUEBEC, P.Q.: 330 St. Roch Street MONTREAL, QUE.: 7865 St. Lawrence Blvd. LONGUEUIL, ONT.: 1568 Chemin De Chambly OTTAWA, ONT.: 285 Richmond Rd. BROCKVILLE, ONT.: Central Avenue SCARBOROUGH, ONT.: 729 Kennedy Road DON MILLS (Toronto), ONT.: 2 Valleybrook Drive THE QUEENSWAY (Toronto), ONT.: 1180 The Queensway	HAMILTON, ONT.: 180 Parkdale Ave. North LONDON, ONT.: 631 Commissioners Rd. I WINNIPEG, ST. JAMES, MAN.: 934 St. James St. REGINA, SASK.: 1076 Albert Street CALGARY, ALTA.: 1003 11th Ave., S.W. EDMONTON, ALTA.: 11440 Ave. 142nd Street VANCOUVER, B.C.: 24 West 2nd Avenue

UTHORIZED SERVICE STATIONS

MANUFACTURING PLANTS

Lancaster, Pa.; Solon, Ohio;
son, Md., Hampstead, Md., U.S.A.;

		AUTHO		
ALABAMA, Montgomery ALASKA, Anchorage Fairbanks ARIZONA, Tucson CALIFORNIA, Fresno Stockton	CONNECTICUT, New Haven DELAWARE, Wilmington FLORIDA, Pensacola IDAHO, Boise, Lewiston INDIANA, South Bend	MA MIS MO NEV NO		

DISTRIBUTION CENTERS

MAINE, Westbrook MINNESOTA, Moorhead MISSISSIPPI, Jackson MONTANA, Billings NEVADA, Reno NORTH CAROLINA, Raleigh

OHIO, Youngstown
PENNSYLVANIA, Allentown
Erie
SOUTH CAROLINA, Charleston
Columbia
SOUTH DAKOTA, Rapid City
WES

OLINA, Charleston VIRGINIA, Roanoke WASHINGTON, Yakima OTA, Rapid City WEST VIRGINIA, Whee

SALES AND SERVICE SUBSIDIARIES Vienna, Austria; Brussels, Belgium; Copenhager Denmark; Dusseldorf, Germany; Mexico, D.F.,

Jenniar, Disasciuli, Gerlinary, Westub, D.T.,
Moniterey, Guadalajara, Mexico; Rotterdam,
New Zealand, Olso, Korway, Johannesburg,
Research, Company, Johannesburg,
Spaln, Goreborg, C. Sweden; Zurich, Switzerland;
Caracius, Venezuela,
BLACK & DECKER, INC., Urbanizacion Industrial
Julia, Caparra Heichts, San Juan, Puerto Rico



"Black & Decker guarantees, for one year from date of purchase, to correct by repair or parts replacement, without charge, any defect due to faulty material of workmanship. Simply return the complete unit, transportation prepaid, to any Black & Decker Service Centre or authorized Service Station. Naturally, we assume no responsibility for damage caused by misuse, careless handling or where repairs have been made or attempted by others. No other guarantee, written or verbal, is authorized by us."


Black & Decker



This tool is protected by Rapid Exchange Service. See guarantee above.

B&D


Black & Decker POWER TOOLS



OWNER'S MANUAL

This booklet is provided for your convenience in the use and care of your new Black & Decker tool. These instructions include operation, safety precautions, preventive maintenance, maintenance and other pertinent data to assist you in assuring long life and dependable service. 4015

HEAVY-DUTY
FINISHING
SANDER
TYPES 1A & 2



PARTS IDENTIFICATION 4015 H.D. FINISHING SANDER, 3.0 AMPS., 10,000 O.P.M.

Inde	ex		ı	Inde	×			,	Inde	x		
No		. Part Description	Quantity	No		. Part Description	Qu	antity	l	Part No	o. Part Description	Quantity
1	57005	ident sticker	1	19	46212-01	lead terminal	-	2	38	65393	#8-32 x 21/8 FH screw	2
2	61037	motor housing	ī	20		field (120V)		1	39	975002	nameplate	1
3	36478	attach. plug (120V)	ī			field (150V)		ī	40	3041	drive screw	2
	37140	attach. plug (150-250V)	ī			field (100V)		ī	41	66181	flexible post	4
4	36480-98	cord & plug (includes	-			field (220V)		1	42	65427	post spacer; includes	
		item 3) (120V)	1	21	61138	bearing retainer		1			item 55 (2)	2
	37142	cord & plug (includes		22	61137	clamp		4	43	58871	base plate	1
		item 3) (150-250V)	1	23	1789	#8-32 x ½ FH screw		4			(includes 44, 45, 46,	47)
5	24288	cord protector	1	24	30611	rubber plug		3	44	58874	spring	2
6	8033	cord clamp	1	25	67140	ball bearing		1	45	58897	bumper	2
7	7895	#8-32 x 1/4 RH screw	1	26	89559-31	armature 120V		1	46	58815	clamp	2
8	418	#8 lockwasher	12		89560-33	armature 150V		1	47	67374	roll pin	2
9	1747	lead terminal	1		89560-35	armature 220V		1	48	5927-01	washer	1
10	20404	#5-40 x 3/32 term. screw	2		89559-55	armature 100V		1	49	416	$\frac{1}{4}$ lockwasher	1
- 11	1991	#6 lockwasher	2	27	58814	fan		1	50	10584	1/4-28 x 3/8 RH screw	1
†12	26192	lead terminal	2	28	58876	spacer		1	51	417	#10 lockwasher	4
13	49352	switch 100-120V	1	29	54301	ball bearing		2	52	34935	#10-32 x ½ screw	4
	62051	switch 150-250V	1	30	61139	bearing retainer		1	53	59998	base plate & pad	1
†14	32114	wire connector	1	31	63896	flexible coupling		1	55	66178	damper pad	4
15	1988	#8-32 x 1/4 RH screw	1	32	89773	eccentric		1			•	
16	46210	br. hold plug	2	33	61140	spring		2	Parts	Not Sho	wn—	
17	46211	brush assembly 100-120\	1 2	34	61038	cover housing		1		59633 c	onnection diagram	
	50946	brush assembly 150-250\	1 2	35	379	#8-32 x 3/4 FH screw	& w	1				
18	61208	brush holder	2	36	640	#8-32 x 1 FH screw		1				
† 0	mit on 150,	220, and 240 volt units.	•	37	99410-38	#8-32 x 2% FH screv	V	3	•	•		

WHEN ORDERING REPLACEMENT PARTS, YOU MUST GIVE UNIT, TYPE AND CATALOG NUMBER AS SHOWN ON NAMEPLATE, PLUS PART NUMBER AND NAME OF PART NEEDED.

MOTOR:


Your Black and Decker tool is powered by a B&D built "Universal" motor. It operates, at nameplate voltage on Alternating Current (25 to 60 cycles) or on Direct Current. Voltage variation of more than 10% will cause loss of power and overheating. All B&D tools are factory-tested; if this tool does not operate, check the following: Supply line for blown fuses; plug and receptacle for contact; carbon brushes.

COMMUTATOR AND BRUSHES:

Inspect carbon brushes often. Replace when brushes are worn down to identifying letter or groove or when spring exerts insufficient pressure to hold brush against commutator. Keep brushes clean and sliding freely in guides. Inspect commutator for dirt and excessive wear. If dirty or rough, clean lightly with very fine sandpaper (not emery cloth). If badly worn or grooved, send tool to our nearest service station for repair (see back page).

GROUNDING:

These units are equipped with approved 3-conductor cord and 3-blade grounding type attachment plug cap to be used with the proper grounding type receptacle, in accordance with the Canadian Electrical Code.



CABLE:

The cable is the "life line" of your tool - keep it clean by wiping it off occasionally. Keep it out of oils and greases which ruin the rubber. Coil it neatly when not in use and avoid dragging it across sharp surfaces or using it as a handle to lift the tool.

Ampere rating (on nameplate)	0 to 2.0	2.10 to 3.4	3.5 to 5.0	5.10 to 7.0	7.10 to 12.0	12.1 to 16.0
Ext. Cable length			Wire Size	e (A.W.G.)		
25 ft.	18	18	18	18	16	14
50 ft.	18	18	18	16	14	12
75 ft.	18	18	16	14	12	10
100 ft.	18	16	14	12	10	_
150 ft.	16	14	12	12		
200 ft.	16	14	12	10		

When using the tool at a considerable distance from power source, an extension cable of adequate size must be used to prevent loss of power and over-heating. Use the table below for 120 volt tools. For 220 volt tools, use wire size corresponding to an extension length of ½ the contemplated length.

SAFETY PRECAUTIONS:

- 1. ALWAYS BE SURE THAT THE TOOL IS PROPERLY GROUNDED.
- 2. BEFORE MAKING ANY ADJUSTMENTS, ATTACHING ABRASIVE PAPER, INSPECTING, CHANGING BRUSHES, OR AT ANY TIME TOOL IS NOT IN USE, BE SURE THAT THE SWITCH IS IN THE "OFF" POSITION AND THAT THE TOOL HAS BEEN DISCONNECTED FROM THE POWER SUPPLY.

SWITCH:

These tools are equipped with a trigger switch and locking pin. To start tool, depress trigger; to stop tool, release trigger. To lock trigger in "ON" position for continuous operation, depress trigger, push in locking pin (located next to trigger), and release trigger. To release locking mechanism and turn tool "OFF", depress and release trigger.

LUBRICATION:

This tool has been completely lubricated at the factory and is ready for use. No further periodic lubrication is necessary. All bearings are closed type, grease sealed ball bearings which require no lubrication.

ATTACHING ABRASIVE PAPER:

- 1. UNPLUG TOOL FROM POWER SUPPLY.
- 2. DEPRESS CLAMP AND HOLD IN OPEN POSITION (see Fig. 2, on back cover), INSERT PAPER AND RELEASE CLAMP.
- 3. DRAW PAPER TIGHT ACROSS PAD TOWARD BACK OF UNIT AND REPEAT SAME OPERATION AS ABOVE.

ACCESSORY AND REPLACEMENT PARTS FOR NO. 4015 SANDER

Model No. 59991. Felt Pad and Plate is available for use as an accessory or replacement part. Model No. 59998. Rubber Pad and Plate (standard with the No. 4015 Sander).

ABRASIVE PAPER 41/2" x 11" size

U1416 60 grit **U1417** 100 grit **U1418** 150 grit